

**AQUAFIN VAPORTIGHT COAT® SG2**  
**MIXING & APPLICATION SEQUENCE**



1. Cut plastic seal and remove safety metal ring.



2. Pierce a hole through the top (rubber membrane) and the bottom of Part B container.



3. Completely drain Part B (hardener) into Part A (resin).



4. Mix for approx. 5 minutes. Use complete kit in the proportions supplied. (Do not alter proportions.)



5. Pour mixed material into a clean container.



6. Carefully mix once more for approx. 30 seconds.



7. Pour appropriate amount of material onto slab and spread evenly with a roller or squeegee.



8. Carefully scrub SG1 or SG2 into the pores with a long handled scrub brush.



9. Follow with a roller to achieve a uniform coverage, and broadcast sand as necessary. Consult product data sheet.



**10. Immediately broadcast sand to rejection (full broadcast) on top of fresh SG1 or SG2.**